User Instructions for Deluxe Beach Wagons



Rottnest Rentals

Thank you for renting the We Love Summer Deluxe Beach Wagon from Rottnest Rentals! This sturdy, foldable beach trolley with canopy and brakes is perfect for transporting beach equipment, umbrellas, chairs, cool bags, and more across the sandy paths and beaches of Rottnest Island.

Featuring large wheels for all-terrain use and a heavy-duty frame, it's designed to make your day out easy and enjoyable.

These instructions incorporate the manufacturer's guidelines from We Love Summer for safe and proper use, along with additional environmental considerations tailored to Rottnest Island's unique ecosystem.

Important: Read all instructions before use. Failure to follow them may result in injury, damage to the product, or environmental harm. This is a rental item—return it clean and undamaged to avoid fees.

SAFETY PECAUTIONS

Follow these guidelines to ensure a safe experience (per manufacturer warnings):

- Total maximum load 120kg (including gear). Do not exceed to avoid instability or damage.
- Not intended for carrying or transporting children. Do not stand or sit in the wagon. This product is not a toy for children.
- Health Considerations: Ensure users can maintain control while pushing/pulling. Avoid use if under influence of alcohol/drugs or fatigue.
- General Warnings:
- Do not locate this product in proximity to an open fire, radiator or heater.
- Inspect for damage before use; report any issues to Rottnest Rentals immediately.
- Use on flat or gently sloping terrain; avoid steep hills to prevent runaway risk.
- Engage brakes when stopped, especially on any slope.
- Failure to follow these warnings could result in serious injury.

Setup and Use

The Deluxe Beach Wagon arrives ready to use or partially folded.

- What's Included: Wagon with heavy-duty steel frame, large 8-9" detachable wheels, telescopic pull handle (and push handle if equipped), removable SPF50+ canopy, brakes.
 - Steps:
 - 1. Unfold the wagon if needed (folds flat for storage).
 - 2. Attach wheels if detached (quick-release for easy transport).
 - 3. Extend telescopic handle for pulling or adjust push handle.
 - 4. Attach removable canopy for shade if desired.
 - 5. Load gear evenly: Distribute weight for balance (heavier items low).
 - Tips: Hose down wheels and frame after sandy use to remove grit and salt.

Usage Guidelines

Transporting: Ideal for hauling hire equipment on island paths and beaches. Stick to designated tracks.

User Instructions for Deluxe Beach Wagons



Rottnest Rentals

On the Island:

- Perfect for Thomson Bay, Parakeet Bay, or other calm areas.
- Use storage for cool bags, towels, snorkel gear.

Restrictions:

- Do not use on very steep terrain or rough rocks.
- Wind Restriction (Rottnest-Specific): Avoid pulling in strong winds exceeding 20 knots if heavily loaded, as it may become unstable or difficult to control.
- Check Bureau of Meteorology or RIA updates.
- No towing behind vehicles or bikes.
- Avoid overloading or uneven loading on slopes.

Environmental Considerations

Rottnest Island is a Class A Reserve with fragile ecosystems, including seagrass meadows, marine life, and native wildlife. As a renter, you play a role in protecting it:

- No Littering: Secure all items to prevent loss. Take all rubbish to shore bins.
- Wildlife Respect: Do not approach or feed guokkas, seals, or birds. Keep 10m distance from animals.
- **Path Protection:** Stick to designated paths and boardwalks to avoid dune erosion or vegetation damage. Do not pull over sensitive areas.
- **Sustainability:** Rinse wagon with fresh water after use to remove salt/sand, prolonging life and reducing corrosion impact.
- **Wind and Weather:** Restrict heavy use in strong winds to avoid accidental disturbance or gear loss in protected areas.

Cleaning and Packing

Steps:

- 1. Empty all compartments and remove sand/debris.
- 2. Rinse with fresh water (especially wheels and body).
- 3. Wipe dry if possible.
- 4. Return in the condition received.

Tips: Manufacturer recommends hosing after each use to maintain condition.

Maintenance and Return

• Return to Rottnest Rentals: Return by 4:00pm. Inspect for damage; fees apply for tears, excessive dirt, or loss (e.g., \$50 cleaning fee, full replacement cost for unrepairable damage). Report any issues upon return.

Contact Information

Rottnest Rentals: 0400 611 855 or crew@rottnestrentals.au for any questions or issues.